

The Design Cabin Community C.I.C, St Mark's Hall, St Mark's Field, Rochford, SS4 1PT United Kingdom

E: venues@tdc.community

W: 0333 335 5369

Bluetooth Outdoor Speaker Instructions

Instructions

English

Power on/off

Long press the power button () for 2 seconds to turn on the speaker and begin Bluetooth pairing, or to turn the speaker off. This process includes voice prompts.

Bluetooth connection

When the speaker is in the Bluetooth pairing mode, turn on your mobile phone's Bluetooth functions, then select "Xiaomi Sound Outdoor" from the Bluetooth pairing list and click to pair. You will hear a prompt when pairing is successful.

To disconnect the speaker, short press 🖹 button 2s and the speaker will switch to Bluetooth pairing mode.

Stereo pair

Short press \odot button each two speakers, and the two nearby speakers will pair automatically and operate as left and right channels respectively.

To disconnect, short press \gtrsim button on either of the speaker.

Multi-speaker pair

Long press \gtrsim button 3s on each speaker, and all speakers will pair automatically*. All speakers will play the same content.

To disconnect, long press button 3s on each speaker.

*Multi-speaker pair function can support at most 100pcs Xiaomi Sound Outdoor pair at the same time.