

Use the touchscreen to turn the urn **ON** and **OFF**

DO NOT turn the urn off at the switch on the wall

The urn goes into a sleep mode after a short period of inactivity. Several different sleep screens may be shown. You will need to touch the screen to wake it up.

Initially, the screen should read **OFF** (unless the previous user forgot to turn it off after use).

Turn it on by touching the ON/OFF symbol at the top of the screen.



While it is heating the water, the screen will display **ON**.

It will show **READY** when it has reached the final temperature.

The urn is filled automatically, and the temperature maintained at the optimal temperature for making tea and coffee.

After use, simply press the ON/OFF symbol to turn the urn off.